


Example diagram of simplified mounting position of modules LR7-54XXX of the European


LR7-54HTH/HTB/HVH/HVB/HVBB/HVD



- This diagram is only intended to guide the static load that the module can withstand, in accordance with IEC61215-2:2016 Static mechanical load test items, when using the clamp mounting method on mono-facial modules, with the clamps fixed in different areas of the module frame.
- This diagram is only applicable to mounting systems in which the mounting rails cross the module frame.
- All other installation requirements must comply with the Mechanical Installation section described in the LONGi Installation Manual.
- This version is exclusively available for Distribution Market in Europe DG.
- LONGi reserves the right of final interpretation.

Example diagram of simplified mounting position of modules LR7-60XXX of the European


LR7-60 HVD/HVH



- This diagram is only intended to guide the static load that the module can withstand, in accordance with IEC61215-2:2016 Static mechanical load test items, when using the clamp mounting method on modules LR7-60XXX, with the clamps fixed in different areas of the module frame.
- This diagram is only applicable to mounting systems in which the mounting rails cross the module frame.
- All other installation requirements must comply with the Mechanical Installation section described in the LONGi Installation Manual.
- This version is exclusively available for Distribution Market in Europe DG.
- LONGi reserves the right of final interpretation.

Example Diagram of Simplified Mounting Position LR7-72XXX of LONGi DG Europe

LR7-72 HTH/HVH/HGD/HVD
LR7-72 HVDF/HVHF (No Short Frame Installation)



- This diagram is only intended to guide the static load that the module can withstand, in accordance with IEC61215-2:2016 Static mechanical load test items, when using the clamp mounting method on modules LR7-72XXX, with the clamps fixed in different areas of the module frame.
- This diagram is only applicable to mounting systems in which the mounting rails cross the module frame.
- All other installation requirements must comply with the Mechanical Installation section described in the LONGi Installation Manual.
- This version is exclusively available for Distribution Market in Europe DG.
- LONGi reserves the right of final interpretation.